

BG96 GNSS

AT Commands Manual

LTE Module Series

Rev. BG96_GNSS_AT_Commands_Manual_V1.0

Date: 2017-06-28



Our aim is to provide customers with timely and comprehensive service. For any assistance, please contact our company headquarters:

Quectel Wireless Solutions Co., Ltd.

7th Floor, Hongye Building, No.1801 Hongmei Road, Xuhui District, Shanghai 200233, China

Tel: +86 21 5108 6236

Email: info@quectel.com

Or our local office. For more information, please visit:

<http://www.quectel.com/support/salesupport.aspx>

For technical support, or to report documentation errors, please visit:

<http://www.quectel.com/support/techsupport.aspx>

Or email to: Support@quectel.com

GENERAL NOTES

QUECTEL OFFERS THE INFORMATION AS A SERVICE TO ITS CUSTOMERS. THE INFORMATION PROVIDED IS BASED UPON CUSTOMERS' REQUIREMENTS. QUECTEL MAKES EVERY EFFORT TO ENSURE THE QUALITY OF THE INFORMATION IT MAKES AVAILABLE. QUECTEL DOES NOT MAKE ANY WARRANTY AS TO THE INFORMATION CONTAINED HEREIN, AND DOES NOT ACCEPT ANY LIABILITY FOR ANY INJURY, LOSS OR DAMAGE OF ANY KIND INCURRED BY USE OF OR RELIANCE UPON THE INFORMATION. ALL INFORMATION SUPPLIED HEREIN IS SUBJECT TO CHANGE WITHOUT PRIOR NOTICE.

COPYRIGHT

THE INFORMATION CONTAINED HERE IS PROPRIETARY TECHNICAL INFORMATION OF QUECTEL CO., LTD. TRANSMITTING, REPRODUCTION, DISSEMINATION AND EDITING OF THIS DOCUMENT AS WELL AS UTILIZATION OF THE CONTENT ARE FORBIDDEN WITHOUT PERMISSION. OFFENDERS WILL BE HELD LIABLE FOR PAYMENT OF DAMAGES. ALL RIGHTS ARE RESERVED IN THE EVENT OF A PATENT GRANT OR REGISTRATION OF A UTILITY MODEL OR DESIGN.

Copyright © Quectel Wireless Solutions Co., Ltd. 2017. All rights reserved.

About the Document

History

Revision	Date	Author	Description
1.0	2017-06-28	Matt YE	Initial

Quectel
Preliminary

Contents

About the Document.....	2
Contents.....	3
Table Index.....	4
1 Introduction	5
1.1. GNSS Turning on/off Procedures	5
1.2. NMEA Sentences Type	6
2 Description of GNSS AT Commands.....	7
2.1. AT+QGPSCFG GNSS Configurations	7
2.1.1. AT+QGPSCFG="outport"[,<outport>]* Configure NMEA Sentences Output Port.....	7
2.1.2. AT+QGPSCFG="nmeasrc"[,<nmeasrc>] Enable/Disable Acquisition of NMEA Sentences via AT+QGPSGNMEA	8
2.1.3. AT+QGPSCFG="gpsnmeatype"[,<gpsnmeatype>] Configure Output Type of GPS NMEA Sentences.....	9
2.1.4. AT+QGPSCFG="glonassnmeatype"[,<glonassnmeatype>] Configure Output Type of GLONASS NMEA Sentences	10
2.1.5. AT+QGPSCFG="galileonmeatype"[,<galileonmeatype>] Configure Output Type of Galileo NMEA Sentences	11
2.1.6. AT+QGPSCFG="beidoumeatype"[,<beidoumeatype>] Configure Output Type of BeiDou NMEA Sentences.....	11
2.1.7. AT+QGPSCFG="gsvextnmeatype"[,<gsvextnmeatype>]* Enable/Disable Output of GSVEXT NMEA Sentences.....	12
2.1.8. AT+QGPSCFG="gnssconfig"[,<gnssconfig>] Configure Supported GNSS Constellation	13
2.1.9. AT+QGPSCFG="autogps"[,<autogps>]* Enable/Disable GNSS to Run Automatically	14
2.2. AT+QGPSDEL Delete Assistance Data	15
2.3. AT+QGPS Turn on GNSS	16
2.4. AT+QGPSEND Turn off GNSS	17
2.5. AT+QGPSLOC* Acquire Positioning Information	17
2.6. AT+QGPSGNMEA Acquire NMEA Sentences.....	19
2.7. AT+QGPSXTRA* Enable gpsOneXTRA Assistance Function.....	21
2.8. AT+QGPSXTRATIME* Inject gpsOneXTRA Time	22
2.9. AT+QGPSXTRADATA* Inject gpsOneXTRA Data File	23
3 Examples	24
3.1. Turn on and off the GNSS.....	24
3.2. Application of GNSS <nmeasrc>	24
4 Appendix A References.....	25
5 Appendix B Summary of Error Codes	27

Table Index

TABLE 1: RELATED DOCUMENT	25
TABLE 2: TERMS AND ABBREVIATIONS	25
TABLE 3: SUMMARY OF ERROR CODES	27

Quectel
Preliminary

1 Introduction

Quectel BG96 module integrates a GNSS engine which supports GPS, BeiDou, Galileo and GLONASS systems, and also it supports gpsOneXTRA* Assistance technology. The high performance GNSS engine is suitable for various applications where lowest-cost and accurate positioning is needed, and it supports position tracking without network assistance. BG96 GNSS can be applied in the following applications: turn-by-turn navigation, asset tracking, buddy tracking, location-aware games, as well as home and fleet management.

NOTE

“*” means under development.

1.1. GNSS Turning on/off Procedures

BG96 GNSS supports location calculation without any assistance from the network. GNSS turning on/off procedures are shown below:

Step 1: Configure GNSS parameters via **AT+QGPSCFG**.

Step 2: Turn on GNSS via **AT+QGPS**.

Step 3: After GNSS is turned on and position is fixed successfully, the positioning information can be obtained in three ways:

- 1) NMEA sentences are output to "usbntmea" port by default; customers can read the port to obtain NMEA sentences.
- 2) Customers can use **AT+QGPSLOC** to obtain positioning information directly, such as latitude, longitude, height, GNSS positioning mode, time, number of satellites, and so on.
- 3) After enabling **<nmeasrc>** via **AT+QGPSCFG="nmeasrc",1**, customers can acquire the specified NMEA sentence via **AT+QGPSGNMEA**. If **<nmeasrc>** is disabled, this command cannot be used.

Step 4: GNSS can be turned off in two ways:

- 1) If the parameter **<fixcount>** of **AT+QGPS** is set to 0 in **Step 2**, GNSS will get position continuously, and it can be turned off via **AT+QGPSEND**.
- 2) If **<fixcount>** reaches the specified value, the GNSS will stop automatically.

1.2. NMEA Sentences Type

The NMEA sentences are compatible with NMEA-0183 Protocol, and all standard NMEA sentences have four kinds of prefix.

For GPS sentences, the prefix is "GP", as below:

- GPGGA - Global positioning system fix data, such as time, position, etc.
- GPRMC - Recommended minimum data
- GPGSV - Detailed satellite data
- GPGSA - Overall satellite data
- GPVTG - Vector track and speed over the ground

For GLONASS sentences, the prefixes are "GL" and "GN", as below:

- GLGSV - Detailed satellite data
- GNGSA - Overall satellite data
- GNGNS - Positioning system

For Galileo sentences, the prefixes are "GA" and "GN", as below:

- GAGSV - Detailed satellite data
- GNGSA - Overall satellite data
- GNGNS - Positioning system

For BeiDou sentences, the prefix is "PQ", as below:

- PQGSV - Detailed satellite data
- PQGSA - Overall satellite data

2 Description of GNSS AT Commands

This chapter mainly introduces the AT commands relating to BG96's GNSS function. All the commands marked with "*" are still under development.

2.1. AT+QGPSCFG GNSS Configurations

The command is used to query and configure various GNSS settings, including NMEA sentences output port, output type of NMEA sentences, and more.

AT+QGPSCFG GNSS Configurations	
Test Command AT+QGPSCFG=?	Response +QGPSCFG: "outport",("none","usbnmea","uartdebug") +QGPSCFG: "nmeasrc",(0,1) +QGPSCFG: "gpsnmeatype",(0-31) +QGPSCFG: "glonassnmeatype",(0-7) +QGPSCFG: "galileonmeatype",(0,1) +QGPSCFG: "beidoumeatype",(0-3) +QGPSCFG: "gsvextnmeatype",(0,1) +QGPSCFG: "gnssconfig",(0-6) +QGPSCFG: "autogps",(0,1) OK
Reference	

2.1.1. AT+QGPSCFG="outport",<outport>* Configure NMEA Sentences Output Port

AT+QGPSCFG="outport",<outport>* Configure NMEA Sentences Output Port	
Write Command AT+QGPSCFG="outport",<outport>]	Response When there are two parameters: OK When the second parameter is omitted, query the current

	setting: +QGPSCFG: "outport",<outport> OK If there is an error related to ME functionality: +CME ERROR: <errcode>
Reference	

Parameter

<outport>	Configure the output port of NMEA sentences, and the configuration parameter will be automatically saved to NVRAM. "none" Close NMEA sentence output "usbnmea" Output via USB NMEA port "uartdebug" Output via UART debug port
<errcode>	Integer type. Indicate the error code of operation. If it is not 0, it is the type of error (Please refer to Chapter 5 for details).

2.1.2. AT+QGPSCFG="nmeasrc"[,<nmeasrc>] Enable/Disable Acquisition of NMEA Sentences via AT+QGPSGNMEA

The command enables/disables acquisition of NMEA sentences via **AT+QGPSGNMEA**.

AT+QGPSCFG="nmeasrc"[,<nmeasrc>] Enable/Disable Acquisition of NMEA Sentences via AT+QGPSGNMEA

Write Command AT+QGPSCFG="nmeasrc"[,<nmeasrc>] >]	Response When there are two parameters: OK When the second parameter is omitted, query the current setting: +QGPSCFG: "nmeasrc",<nmeasrc> OK If there is an error related to ME functionality: +CME ERROR: <errcode>
Reference	

Parameter

<nmeasrc>	If enabled, original NMEA sentences can be acquired via AT+QGPSGNMEA , and the configuration parameter will be automatically saved to NVRAM. Meanwhile, sentences are output via the same NMEA ports as before. 0 Disable <u>1</u> Enable
<errcode>	Indicate the error code of operation. If it is not 0, it is the type of error (Please refer to Chapter 5 for details).

2.1.3. AT+QGPSCFG="gpsnmeatype"[,<gpsnmeatype>] Configure Output Type of GPS NMEA Sentences

AT+QGPSCFG="gpsnmeatype"[,<gpsnmeatype>] Configure Output Type of GPS NMEA Sentences

Write Command AT+QGPSCFG="gpsnmeatype"[,<gpsnmeatype>]	Response When there are two parameters: OK When the second parameter is omitted, query the current setting: +QGPSCFG: "gpsnmeatype",<gpsnmeatype> OK If there is an error related to ME functionality: +CME ERROR: <errcode>
Reference	

Parameter

<gpsnmeatype>	Output type of GPS NMEA sentences by ORed, and the configuration parameter will be automatically saved to NVRAM. The default value is 31 which means that all the five types of sentences will be output. 0 Disable 1 GGA 2 RMC 4 GSV 8 GSA 16 VTG
<errcode>	Indicate the error code of operation. If it is not 0, it is the type of error (Please refer to Chapter 5 for details).

refer to **Chapter 5** for details).

2.1.4. AT+QGPSCFG="glonassnmeatype"[,<glonassnmeatype>] Configure Output

Type of GLONASS NMEA Sentences

AT+QGPSCFG="glonassnmeatype"[,<glonassnmeatype>] Configure Output Type of GLONASS NMEA Sentences

Write Command

AT+QGPSCFG="glonassnmeatype"[,<glonassnmeatype>]

Response

When there are two parameters:

OK

When the second parameter is omitted, query the current setting:

+QGPSCFG: "glonassnmeatype",<glonassnmeatype>

OK

If there is an error related to ME functionality:

+CME ERROR: <errcode>

Reference

Parameter

<glonassnmeatype>

Configure output type of GLONASS NMEA sentences by ORed, and the configuration parameter will be automatically saved to NVRAM. The default value is 0.

0 Disable

1 GSV

2 GSA

4 GNS

<errcode>

Indicate the error code of operation. If it is not 0, it is the type of error (Please refer to **Chapter 5** for details).

2.1.5. AT+QGPSCFG="galileonmeatype"[,<galileonmeatype>] Configure Output

Type of Galileo NMEA Sentences

AT+QGPSCFG="galileonmeatype"[,<galileonmeatype>] Configure Output Type of Galileo NMEA Sentences

Write Command AT+QGPSCFG="galileonmeatype"[,<galileonmeatype>]	Response When there are two parameters: OK When the second parameter is omitted, query the current setting: +QGPSCFG: "galileonmeatype",<galileonmeatype> OK If there is an error related to ME functionality: +CME ERROR: <errcode>
Reference	

Parameter

<galileonmeatype>	Configure output type of Galileo NMEA sentences by ORed, and the configuration parameter will be automatically saved to NVRAM. The default value is 0. <u>0</u> Disable 1 GSV
<errcode>	Indicate the error code of operation. If it is not 0, it is the type of error (Please refer to Chapter 5 for details).

2.1.6. AT+QGPSCFG="beidoumeatype"[,<beidoumeatype>] Configure Output

Type of BeiDou NMEA Sentences

AT+QGPSCFG="beidoumeatype"[,<beidoumeatype>] Configure Output Type of BeiDou NMEA Sentences

Write Command AT+QGPSCFG="beidoumeatype"[,<beidoumeatype>]	Response When there are two parameters: OK When the second parameter is omitted, query the current setting:
--	---

	<p>+QGPSCFG: "beidoumeatype",<beidoumeatype></p> <p>OK</p> <p>If there is an error related to ME functionality: +CME ERROR: <errcode></p>
Reference	

Parameter

<beidoumeatype>	<p>Configure output type of BeiDou NMEA sentences via ORed, and the configuration parameter will be automatically saved to NVRAM. The default value is 0.</p> <table border="0"> <tr> <td style="padding-right: 20px;">0</td> <td>Disable</td> </tr> <tr> <td>1</td> <td>GSA</td> </tr> <tr> <td>2</td> <td>GSV</td> </tr> </table>	0	Disable	1	GSA	2	GSV
0	Disable						
1	GSA						
2	GSV						
<errcode>	<p>Indicate the error code of operation. If it is not 0, it is the type of error (Please refer to Chapter 5 for details).</p>						

2.1.7. AT+QGPSCFG="gsvextnmeatype"[,<gsvextnmeatype>]* Enable/Disable

Output of GSVEXT NMEA Sentences

AT+QGPSCFG="gsvextnmeatype"[,<gsvextnmeatype>]* Enable/Disable Output of GSVEXT NMEA Sentences

<p>Write Command</p> <p>AT+QGPSCFG="gsvextnmeatype"[,<gsvextnmeatype>]</p>	<p>Response</p> <p>When there are two parameters: OK</p> <p>When the second parameter is omitted, query the current setting: +QGPSCFG: "gsvextnmeatype",<gsvextnmeatype></p> <p>OK</p> <p>If there is an error related to ME functionality: +CME ERROR: <errcode></p>
Reference	

Parameter

<gsvextnmeatype>	Enable/disable output of extended GSV information. Elevation/Azimuth/SNR (C/No) will be displayed as decimals when extended information is enabled, otherwise they will be displayed as integers. The configuration parameter will be automatically saved to NVRAM. The default value is 0. 0 Disable 1 Enable
<errcode>	Indicate the error code of operation. If it is not 0, it is the type of error (Please refer to Chapter 5 for details).

2.1.8. AT+QGPSCFG="gnssconfig"[,<gnssconfig>] Configure Supported GNSS

Constellation

AT+QGPSCFG="gnssconfig"[,<gnssconfig>] Configure Supported GNSS Constellation	
Write Command AT+QGPSCFG="gnssconfig"[,<gnssconfig>]	Response When there are two parameters: OK When the second parameter is omitted, query the current setting: +QGPSCFG: "gnssconfig",<gnssconfig> OK If there is an error related to ME functionality: +CME ERROR: <errcode>
Reference	

Parameter

<gnssconfig>	Supported GNSS constellation. GPS is always on. 0 GLONASS off/BeiDou off/Galileo off 1 GLONASS on/BeiDou on/Galileo on 2 GLONASS on/BeiDou on/Galileo off 3 GLONASS on/BeiDou off/Galileo on 4 GLONASS on/BeiDou off/Galileo off 5 GLONASS off/BeiDou on/Galileo on 6 GLONASS off/BeiDou off/Galileo on
---------------------------	--

<errcode> Indicate the error code of operation. If it is not 0, it is the type of error (Please refer to **Chapter 5** for details).

NOTE

The command will be effective after restart.

2.1.9. AT+QGPSCFG="autogps"[,<autogps>]* Enable/Disable GNSS to Run Automatically

AT+QGPSCFG="autogps"[,<autogps>]* Enable/Disable GNSS to Run Automatically

Write Command	Response
AT+QGPSCFG="autogps"[,<autogps>]>]	When there are two parameters: OK
	When the second parameter is omitted, query the current setting: +QGPSCFG: "autogps",<autogps>
	OK
	If there is an error related to ME functionality: +CME ERROR: <errcode>

Reference

Parameter

<autogps> Enable/disable GNSS to run automatically after the module is powered on. Configuration parameter will be automatically saved to NVRAM. The default value is 0.

0 Disable GNSS to run automatically
1 Enable GNSS to run automatically

<errcode> Indicate the error code of operation. If it is not 0, it is the type of error (Please refer to **Chapter 5** for details).

NOTE

The command is only valid in **Stand-alone** Solution.

2.2. AT+QGPSDEL Delete Assistance Data

Delete assistance data to operate cold start, hot start and warm start of GNSS. The command can only be executed when GNSS is turned off. After deleting the assistance data via this command, cold start of GNSS can be enforced via **AT+QGPS**. Hot/warm start can also be performed if the corresponding conditions are satisfied.

AT+QGPSDEL Delete Assistance Data

Test Command AT+QGPSDEL=?	Response +QGPSDEL: (0-3) OK
Write Command AT+QGPSDEL=<deletetype>	Response OK If there is an error related to ME functionality: +CME ERROR: <errcode>
Reference	

Parameter

<deletetype>	The type of GNSS assistance data to be deleted. 0 Delete all assistance data except gpsOneXTRA data. Enforce cold start after starting GNSS. 1 Do not delete any data. Perform hot start if the conditions are permitted after starting GNSS. 2 Delete some related data. Perform warm start if the conditions are permitted after starting GNSS. 3* Delete the gpsOneXTRA assistance data injected into GNSS engine.
<errcode>	Indicate the error code of operation. If it is not 0, it is the type of error (Please refer to Chapter 5 for details).

NOTE

“*” means under development.

2.3. AT+QGPS Turn on GNSS

The command is used to turn on GNSS function. Currently **<gnssmode>** only supports turning on GNSS in **Stand-alone** Solution. When **<fixcount>** is 0, GNSS will fix position continuously, and it can be turned off via **AT+QGPSEND**. When **<fixcount>** is non-zero and reaches the specified value, GNSS will be turned off automatically.

AT+QGPS Turn on GNSS

Test Command AT+QGPS=?	Response +QGPS: (1-4),(1-255),(1-1000),(0-1000),(1-65535) OK
Read Command Read current GNSS state AT+QGPS?	Response +QGPS: <gnssstate> OK
Write Command AT+QGPS=<gnssmode>[,<fixmaxtime>[,<fixmaxdist>[,<fixcount>[,<fixrate>]]]]	Response OK If there is an error related to ME functionality: +CME ERROR: <errcode>
Reference	

Parameter

<gnssstate>	GNSS state. <u>0</u> GNSS OFF 1 GNSS ON
<gnssmode>	GNSS working mode <u>1</u> Stand-alone 2 MS-based 3 MS-assisted 4 Speed-optimal
<fixmaxtime>	The maximum positioning time (unit: s). Indicate the response time of GNSS receiver while measuring the GNSS pseudo range, and the upper time limit of GNSS satellite searching. It also includes the time for demodulating the ephemeris data and calculating the position. 1- <u>30</u> -255 Maximum positioning time
<fixmaxdist>	Accuracy threshold of positioning. Unit: m. 1- <u>50</u> -1000
<fixcount>	Number of attempts for positioning.

	0–1000	0 indicates continuous positioning. Non-zero values indicate the actual number of attempts for positioning.
<fixrate>		The interval time between the first and second time positioning. Unit: s.
	1–65535	
<errcode>		Indicate the error code of operation. If it is not 0, it is the type of error (Please refer to Chapter 5 for details).

2.4. AT+QGPSEND Turn off GNSS

When GNSS is turned on and <fixcount> is 0, GNSS fixes position continuously. In this case, GNSS can be turned off compulsorily via **AT+QGPSEND**. When <fixcount> is non-zero, GNSS will be turned off automatically when the parameter reaches the specified value, and thus the command can be ignored.

AT+QGPSEND Turn off GNSS

Test Command AT+QGPSEND=?	Response OK
Execution Command AT+QGPSEND	Response OK If there is an error related to ME functionality: +CME ERROR: <errcode>
Reference	

Parameter

<errcode>	Indicate the error code of operation. If it is not 0, it is the type of error (Please refer to Chapter 5 for details).
-----------	---

2.5. AT+QGPSLOC* Acquire Positioning Information

Before executing the command, GNSS must be turned on via **AT+QGPS**. If it fails in position fix, **+CME ERROR: <errcode>** will be returned to indicate the corresponding situation.

AT+QGPSLOC* Acquire Positioning Information

Test Command AT+QGPSLOC=?	Response +QGPSLOC: <UTC>,<latitude>,<longitude>,<hdop>,<altitude>,<fix>,<c
-------------------------------------	---

	og>,<spkm>,<spkn>,<date>,<nsat>
	OK
Write Command AT+QGPSLOC=<mode>	Response +QGPSLOC: <UTC>,<latitude>,<longitude>,<hdop>,<altitude>,<fix>,<code>,<spkm>,<spkn>,<date>,<nsat>
	OK
	If there is an error related to ME functionality: +CME ERROR: <errcode>
Reference	

Parameter

<mode>	Latitude and longitude display format. 0 <latitude>,<longitude> format: ddmm.mmmm N/S,dddmm.mmmm E/W 1 <latitude>,<longitude> format: ddmm.mmmmmm N/S,dddmm.mmmmmm E/W 2 <latitude>,<longitude> format: (-)dd.ddddd,(-)ddd.ddddd
<UTC>	UTC time. Format: hhmmss.sss (Quoted from GPGLL sentence).
<latitude>	Latitude. If <mode> is 0: Format: ddmm.mmmm N/S (Quoted from GPGLL sentence) dd 00-89 (degree) mm.mmmm 00.0000-59.9999 (minute) N/S North latitude/South latitude If <mode> is 1: Format: ddmm.mmmmmm N/S (Quoted from GPGLL sentence) dd 00-89 (degree) mm.mmmmmm 00.000000-59.999999 (minute) N/S North latitude/South latitude If <mode> is 2: Format: (-)dd.ddddd (Quoted from GPGLL sentence) dd.ddddd -89.99999-89.99999 (degree) - South latitude
<longitude>	Longitude. If <mode> is 0: Format: dddmm.mmmm E/W (Quoted from GPGLL sentence) ddd 000-179 (degree) mm.mmmm 00.0000-59.9999 (minute) E/W East longitude/West longitude

	If <mode> is 1:
	Format: dddmm.mmmmmm E/W (Quoted from GPGLGA sentence)
	ddd 000-179 (degree)
	mm.mmmmmm 00.000000-59.999999 (minute)
	E/W East longitude/West longitude
	If <mode> is 2:
	Format: (-)dd.ddddd (Quoted from GPGLGA sentence)
	dd.ddddd -179.99999-179.99999 (degree)
	- West longitude
<hdop>	Horizontal precision: 0.5-99.9 (Quoted from GPGLGA sentence).
<altitude>	The altitude of the antenna away from the sea level (unit: m), accurate to one decimal place (Quoted from GPGLGA sentence)
<fix>	GNSS positioning mode (Quoted from GNGSA/GPGSA sentence).
	2 2D positioning
	3 3D positioning
<cog>	Course Over Ground based on true north.
	Format: ddd.mm (Quoted from GPVTG sentence).
	ddd 000-359 (degree)
	mm 00-59 (minute)
<spkm>	Speed over ground.
	Format: xxxx.x; unit: Km/h; accurate to one decimal place (Quoted from GPVTG sentence).
<spkn>	Speed over ground.
	Format: xxxx.x; unit: knots; accurate to one decimal place (Quoted from GPVTG sentence).
<date>	UTC time when fixing position.
	Format: ddmmyy (Quoted from GPRMC sentence).
<nsat>	Number of satellites, from 00 (The first 0 should be retained) to 12 (Quoted from GPGLGA sentence).
<errcode>	Indicate the error code of operation. If it is not 0, it is the type of error (Please refer to Chapter 5 for details).

2.6. AT+QGPSGNMEA Acquire NMEA Sentences

Before using this command, GNSS must be turned on via **AT+QGPS**, and **<nmeasrc>** has to be enabled via **AT+QGPSCFG="nmeasrc",1**.

If parameters **<gpsnmeatype>**, **<glonassnmeatype>**, **<galileonmeatype>** and **<beidoumeatype>** are all 0, the command can be used to acquire NMEA sentences. If the GNSS has already acquired sentences via this command after its activation, customers can disable sentences output via **AT+QGPSCFG="gpsnmeatype"/"glonassnmeatype"/"galileonmeatype"/"beidoumeatype",0**.

Then the sentences obtained via **AT+QGPSGNMEA** are the last sentences.

AT+QGPSGNMEA Acquire NMEA Sentences

<p>Test Command AT+QGPSGNMEA=?</p>	<p>Response +QGPSGNMEA: ("GGA","RMC","GSV","GSA","VTG","GNS")</p> <p>OK</p>
<p>Inquiry Command Query GGA sentence AT+QGPSGNMEA="GGA"</p>	<p>Response +QGPSGNMEA: GGA sentence</p> <p>OK</p> <p>If there is an error related to ME functionality: +CME ERROR: <errcode></p>
<p>Inquiry Command Query RMC sentence AT+QGPSGNMEA="RMC"</p>	<p>Response +QGPSGNMEA: RMC sentence</p> <p>OK</p> <p>If there is an error related to ME functionality: +CME ERROR: <errcode></p>
<p>Inquiry Command Query GSV sentence AT+QGPSGNMEA="GSV"</p>	<p>Response +QGPSGNMEA: GSV sentence</p> <p>OK</p> <p>If there is an error related to ME functionality: +CME ERROR: <errcode></p>
<p>Inquiry Command Query GSA sentence AT+QGPSGNMEA="GSA"</p>	<p>Response +QGPSGNMEA: GSA sentence</p> <p>OK</p> <p>If there is an error related to ME functionality: +CME ERROR: <errcode></p>
<p>Inquiry Command Query VTG sentence AT+QGPSGNMEA="VTG"</p>	<p>Response +QGPSGNMEA: VTG sentence</p> <p>OK</p> <p>If there is an error related to ME functionality: +CME ERROR: <errcode></p>
<p>Inquiry Command Query GNS sentence</p>	<p>Response +QGPSGNMEA: GNS sentence</p>

AT+QGPSGNMEA="GNS"	OK If there is an error related to ME functionality: +CME ERROR: <errcode>
Reference	

Parameter

<errcode>	Indicate the error code of operation. If it is not 0, it is the type of error (Please refer to Chapter 5 for details).
------------------------	---

2.7. AT+QGPSXTRA* Enable gpsOneXTRA Assistance Function

This command can be used to enable gpsOneXTRA Assistance function, and the function can be activated after restarting the module.

AT+QGPSXTRA* Enable gpsOneXTRA Assistance Function

Test Command AT+QGPSXTRA=?	Response +QGPSXTRA: (0,1) OK
Read Command AT+QGPSXTRA?	Response +QGPSXTRA: <xtraenable> OK
Write Command AT+QGPSXTRA=<xtraenable>	Response OK If there is an error related to ME functionality: +CME ERROR: <errcode>
Reference	

Parameter

<xtraenable>	Enable gpsOneXTRA Assistance function, and the configuration parameter will be automatically saved to NVRAM.
0	Disable gpsOneXTRA Assistance
1	Enable gpsOneXTRA Assistance

<errcode> Indicate the error code of operation. If it is not 0, it is the type of error (Please refer to **Chapter 5** for details).

2.8. AT+QGPSXTRATIME* Inject gpsOneXTRA Time

This command can be used to inject gpsOneXTRA time to GNSS engine. Before using it, customers must enable gpsOneXTRA Assistance function via **AT+QGPSXTRA=1** command. After activating the function, the GNSS engine will ask for gpsOneXTRA time and assistance data file. Before injecting gpsOneXTRA data file, gpsOneXTRA time must be injected first via this command.

AT+QGPSXTRATIME* Inject gpsOneXTRA Time

Test Command AT+QGPSXTRATIME=?	Response +QGPSXTRATIME: 0,<xtratime>,(0,1),(0,1),<uncrtn> OK
Write Command Inject gpsOneXTRA time AT+QGPSXTRATIME=<op>,<xtratime> >[,<utc>[,<force>,<uncrtn>]]	Response OK If there is an error related to ME functionality: +CME ERROR: <errcode>
Reference	

Parameter

<op>	Operation type. 0 Inject gpsOneXTRA time
<xtratime>	Current UTC/GPS time. Format: YYYY/MM/DD,hh:mm:ss. e.g. 2016/01/03,15:34:50.
<utc>	The type of time. 0 GPS time 1 UTC time
<force>	Allow or force GPS subsystem to accept the time injected. 0 Allow acceptance 1 Force acceptance
<uncrtn>	Uncertainty of time. Unit: ms. Default value: 3500ms. It indicates the time difference between sending a request to the SNTP server and receiving a response from the SNTP server. If the set time is less than 3.5s, it will be counted as 3.5s.
<errcode>	Indicate the error code of operation. If it is not 0, it is the type of error (Please refer to Chapter 5 for details).

2.9. AT+QGPSXTRADATA* Inject gpsOneXTRA Data File

This command can be used to inject gpsOneXTRA assistance data file to GNSS engine. Before operating this command, customers must enable gpsOneXTRA, store the valid gpsOneXTRA data file into RAM or UFS (RAM is recommended) of the module and inject gpsOneXTRA time to GNSS engine. After operating this command successfully, gpsOneXTRA data file can be deleted from RAM file, and customers can query whether the gpsOneXTRA data is injected successfully via **AT+QGPSXTRADATA?**.

AT+QGPSXTRADATA* Inject gpsOneXTRA Data File

Test Command AT+QGPSXTRADATA=?	Response +QGPSXTRADATA: <xtradatafilename> OK
Read Command Query the status of gpsOneXTRA data file AT+QGPSXTRADATA?	Response +QGPSXTRADATA: <xtradatadurtime>,<injecteddatatime> OK If there is an error related to ME functionality: +CME ERROR: <errcode>
Write Command Inject gpsOneXTRA data file AT+QGPSXTRADATA=<xtradatafilename>	Response OK If there is an error related to ME functionality: +CME ERROR: <errcode>
Reference	

Parameter

<xtradatafilename>	Filename of the gpsOneXTRA data file, e.g. <i>xtra.bin</i> or <i>xtra2.bin</i> .
<xtradatadurtime>	Valid time of injected gpsOneXTRA data file. Unit: min. 0 No gpsOneXTRA file or the file is overdue 1-10080 Valid time of gpsOneXTRA file
<injecteddatatime>	Starting time of the valid time of gpsOneXTRA data file. Format: YYYY/MM/DD, hh:mm:ss, e.g. 2016/01/03,15:34:50.
<errcode>	Indicate the error code of operation. If it is not 0, it is the type of error (Please refer to Chapter 5 for details).

3 Examples

3.1. Turn on and off the GNSS

Default arguments are used in this example to turn on GNSS. After turning on GNSS, NMEA sentences will be output from “usbntea” port by default; and GNSS can be turned off via **AT+QGSEND**.

```
AT+QGPS=1 //Turn on GNSS.
OK
//After turning on GNSS, NMEA sentences will be output from “usbntea” port by default.
AT+QGPSLOC? //Obtain positioning information.
+QGPSLOC: 061951.0,3150.7223N,11711.9293E,0.7,62.2,2,0.0,0.0,0.0,110513,09
OK
AT+QSEND //Turn off GNSS.
OK
```

3.2. Application of GNSS <nmeasrc>

When GNSS is turned on and <nmeasrc> is enabled, NMEA sentences can be acquired directly via **AT+QPSGNMEA**.

```
AT+QPSCFG="nmeasrc",1 //Enable <nmeasrc> functionality.
OK
AT+QPSGNMEA="GGA" //Obtain GGA sentence.
+QPSGNMEA: $GPGGA,103647.0,3150.721154,N,11711.925873,E,1,02,4.7,59.8,M,-2.0,M,,*77
OK
AT+QPSCFG="nmeasrc",0 //Disable <nmeasrc> functionality.
OK
AT+QPSGNMEA="GGA" //Disable <nmeasrc> functionality, and thus GGA sentence
cannot be obtained.
+CME ERROR: 507
```

4 Appendix A References

Table 1: Related Document

SN	Document Name	Remark
[1]	Quectel_QCOM_User_Guide	QCOM user guide

Table 2: Terms and Abbreviations

Abbreviation	Description
BeiDou	BeiDou Navigation Satellite System
Galileo	Galileo Satellite Navigation System
GGA	Global Positioning System Fix Data
GLONASS	Global Navigation Satellite System
GNS	Global Network Service
GNSS	Global Navigation Satellite System
GPS	Global Positioning System
gpsOneXTRA	An Auxiliary Positioning Technology Provided by Qualcomm
GSA	GPS DOP and Active Satellites
GSV	Satellites in View
MCU	Micro Control Unit
ME	Mobile Equipment
MS	Mobile Station
NMEA	National Marine Electronics Association
NVRAM	Non-Volatile Random Access Memory
PC	Private Computer

RAM	Random Access Memory
RMC	Recommended Minimum Navigation Information
SNR	Signal Noise Ratio
SNTP	Simple Network Time Protocol
TTF	Time to First Fix
UART	Universal Asynchronous Receiver & Transmitter
URL	Uniform Resource Locator
USB	Universal Serial Bus
UTC	Universal Time Code
VTG	Track Made Good and Ground Speed

Quectel
Preliminary

5 Appendix B Summary of Error Codes

The **<errcode>** indicates an error related to GNSS operation. The details about **<errcode>** are described in the following table.

Table 3: Summary of Error Codes

<errcode>	Meaning
501	Invalid parameter(s)
502	Operation not supported
503	GNSS subsystem busy
504	Session is ongoing
505	Session not active
506	Operation timeout
507	Function not enabled
508	Time information error
512	Validity time is out of range
513	Internal resource error
514	GNSS locked
515	End by E911
516	Not fixed now
549	Unknown error